






INSTALLATION INSTRUCTION MANUAL

SIDE PULL GATE INSTALL


SIDE PULL GATE INSTALL | STEP 1.

Using the eight screws provided with the D&D Tru Close Hinge set, attach the hinges to the post face and gate frame on the outer side of the fence. Hinges must be 900mm apart for compliance.



SIDE PULL GATE INSTALL | STEP 2.


On the inside of the gate attach the side pull latch using the provided screws. The center of the latch body must sit 150mm minimum from top of post.



SIDE PULL GATE INSTALL | STEP 3.

Using the four screws provided with the D&D Gate Stop, attach the gate stop to the gate frame on the outer side of the fence. Center align the stop gate with the latch.


SPECIFICATIONS



STANDARD GATE

QTY: as required


- Pure Perf or Design Perf
- AS1926.1 tested pool fence system
- Powder coated 2.5mm aluminium



D&D SIDE PULL LATCH

QTY: 1 per gate


- Textured black finish
- Quality strong material
- Magnetic latching device
- Pool fencing compliant
- Supplied with installation instructions & appropriate fixings



D&D TRU CLOSE HINGES

QTY: 2 per gate

- Textured black finish
- Quality strong material
- Self closing & tension adjusting
- Supplied with installation instructions & appropriate fixings



D&D STOP GATE

QTY: 1 per gate

- Textured black finish
- Quality strong material
- Significantly reduces slamming
- Pool fencing compliant
- Supplied with installation instructions & appropriate fixings